

Product Data

Chemical Spill Station

Cairn Technology's Chemical Spill Station is the culmination of a long period of careful development. We have drawn on the experience of professionals working with hazardous chemicals in a large number of NHS and private hospitals working in a wide variety of environments.

The Chemical Spill Station is available in two formats:

- Fixed – wall-mounted base station;
- Mobile – fast response case

The fixed design is ideal for situations where the nature and location of the risk can be readily identified e.g. Endoscopy and Theatre departments where washer-disinfectors are used.

The mobile case is designed to be wall-mounted and easy to carry to the location of the spillage.

The Fixed Base Station & Fast Response Case

The mobile case and fixed base station are manufactured in fire-resistant, anti-fungal, anti-bacterial wipe-clean material.

The Spill Stations have an integral document section for relevant Material Safety Data Sheets and other important COSHH documentation.



Both Spill Stations have been designed to facilitate a rapid response to an incident, they can be:

- readily sited in a suitable location (hooks supplied), and are;
- bright 'hazard' yellow
- easy to use

In the event of an emergency the user is presented with three sections, each in a clear plastic QuickBag.





Product Data

The *QuickBags* each contain the following items:

Personal Protective Equipment:

Each set of PPE consists of:

- gloves (latex free, chemical resistant)
- gown (chemical resistant) – to cover clothes and exposed skin
- over-boots (chemical resistant) – to ensure chemical does not splash onto exposed skin
- Moldex respirator with ABEK1P3 or A2P2 filter – to protect against chemical fumes & vapours
- goggles – to protect against splashes and aerosols

It is recommended that the Chemical Spill Station should contain two sets of PPE. There is an option to purchase the Stations with one set of PPE.

Clean-up Equipment:

The Spill Mop system can be used to rapidly and safely control large and small volumes of hazardous liquid:

- 1 3-stage mop handle
- 1 polypropylene mop base;
- 10 spill mop heads (3 litres absorbency each)
- 15 spill mop absorbent pads (0.9 litres absorbency each)

The Mop design allows the user to deal with the spill from a safer distance. The super-absorbent polymer core traps liquids forming a gel thereby minimising the hazard due to evaporation or dripping of the chemical.



Waste Disposal Equipment

Equipment to dispose of waste material and used equipment:

- 5 'Special Waste' bags and plastic 'click-ties'

The integral section also contains:

- 2 laminated 'Caution' signs
- 4m yellow/black barrier tape
- 1 laminated chemical spill station sign
- 1 laminated chemical emergency procedure
- 1 detailed chemical emergency procedure – section 5 (bound)
- 1 incident and re-order form
- 1 training course product data sheet
- 1 batch number label

For more information about this and other products, or to place an order, please call us on 0114 244 9551.

